PARTS LIST

ELECTRICAL

Control board 20-1836
Shield for above.....20-2271
Ground wire for above 20-2270
Power board 20-1845
3A (amp) fuse (5mm x 20mm) Type F,
for Power board 20-1698
Cable, control board 20-1837
Pressure transducer 20-1857
Temperature sensor 67-0052
High side level sensor 77-0534
Drainer and low side level sensor 77-0535
Solenoid coil kit, 230V for DIN plug 70-1055
Solenoid coil kit, 115V for DIN plug 70-1054
DIN plug connector with gasket 70-0316

MECHANICAL

Solenoid tube/plunger kit 70-1059
Water solenoid valve (D), less coil .....HS2B(10)
APM bubbler 20-1959
Strainer/orifice screen assembly kit
includes strainer/orifice screen
assembly and necessary O-rings 20-2177
Water flow controller 20-1985
Removable seat/orifice kits
For solenoid valve (B) or (C) 70-1068
For solenoid valve (A) 70-1069
80 psid check valve.....20-1949
Foul gas/liquid line strainer kits include
strainer basket and O-ring 78-1010

Back